

## Installation Instructions



1. Stretch 1/4 of the TrackSock™ over the track as illustrated in Step 1 above.
2. Turn the machine ON and drive approximately 2 feet backward. Power machine off and continue stretching the TrackSock™ forward over the track.
3. Repeat step 2 as needed until TrackSock™ is covering the entire track. Please note that it will be necessary to drive a full circle of the track to complete installation.

**TrackSocks®**

Open Camera  
Scan Code  
Learn More



### NOTES

- To remove, pull the top section of the TrackSock™ completely off each track and drive the machine forward.
- Make certain you have a clear and straight drive path prior to beginning installations and/or removal of this product.
- TrackSocks™ are only to be used on interior projects and always on a flat level surface.
- Do not drive on wet, rough or exterior concrete.

**Questions? Call Us 1.888.SOCK.911**

### WARNING

**The machine should always be OFF with the key removed during each step of the installation and removal of this product.**