

# Installation Instructions



1. Stretch the AerialJacket® over the basket making sure that the opening is toward the arm on the machine with the logo facing front. Once you have covered the basket, straighten, secure, and zip the cover closed.
2. To secure the cover to the machine, run the retractable lock through the grommet holes and through the zipper pull at the base of the AerialJacket®.

**AerialJackets®**

Open Camera  
Scan Code  
▶ Watch Install



## NOTES

- AerialJackets® protect your equipment during transport and from the elements, dust, and debris.
- Constructed of heavy-duty water-resistant fabrics.
- Bungee base provides a snug, secure fit.

Questions? Call Us 1.888.SOCK.911

## WARNING

The machine should always be OFF with the key removed during each step of the installation and removal of this product.

# Installation Instructions



1. Stretch the AerialJacket® over the control panel length-wise making sure that the opening with logo is centered over the controls. Once you have covered the control panel, straighten, secure, and close the cover.
2. To secure the cover to the machine, run the retractable lock through the grommet holes and through the zipper pull at the base of the AerialJacket®.

**AerialJackets®**

Open Camera  
Scan Code  
▶ Watch Install



## NOTES

- Zippered opening allows access to controls without having to remove the cover.
- Velcro backing allows you to secure flap while open.
- Extra bungee provided to further secure the cover.
- AerialJackets® protect your equipment during transport and from the elements, dust, and debris.
- Constructed of heavy-duty, water-resistant fabrics.
- Bungee base provides a snug, secure fit.

**Questions? Call Us 1.888.SOCK.911**

## WARNING

**The machine should always be OFF with the key removed during each step of the installation and removal of this product.**

# Installation Instructions



1. Stretch the AerialJacket® over the machine length-wise making sure that the opening is toward the entry point of the machine (logo will be on the sides). Once you have covered the machine, straighten, secure, and close the cover.
2. To secure the cover to the machine, run the retractable lock through the grommet holes and through the zipper pull at the base of the AerialJacket®.

**AerialJackets®**

Open Camera  
Scan Code  
▶ Watch Install



## NOTES

- Additional grommet holes on the sides of the AerialJacket® can be used with the included bungee to further secure the cover.
- Zippered opening allows access to charging port without having to remove the cover.
- AerialJackets® protect your equipment during transport and from the elements, dust, and debris.
- Constructed of heavy-duty, water-resistant fabrics.

**Questions? Call Us 1.888.SOCK.911**

## WARNING

The machine should always be OFF with the key removed during each step of the installation and removal of this product.

# Installation Instructions



1. Remove control box from machine.
2. Stretch the AerialJacket® over the control box length-wise making sure that the logo and slit face outward. The control box hook goes up through the slit and is visible above the logo.
3. Re-attach control box to machine and straighten and secure the cover.
4. To secure the cover run the retractable lock through the grommet holes at the base of the AerialJacket®.

## **NOTES**

- AerialJackets® protect your equipment during transport and from the elements, dust, and debris.
- Constructed of heavy-duty, water-resistant fabrics.

**Questions? Call Us 1.888.SOCK.911**

## **WARNING**

**The machine should always be OFF with the key removed during each step of the installation and removal of this product.**